

No	Part Name	Q'ty
1	HEX BOLT 1/4" (PARAPET)	8
2	HEX BOLT 16x20 (SUS)	2
3	ANCHOR 1/4" (SUS)	8
4	SCREW PH M4x8 (SUS)	4
5	RUBBER GASKET (SILICON)	1
6	SEAL TAPE (12mm)	1
7	PH MS M3x10(SUS)	2

MNTZ36PP Parapet Mount Bracket User's Manual

ATTENTION: Make sure the o-rings are attached to the mounting screws and dome cover torx screws to prevent water ingress.

Installing the camera into the camera adapter:

- ① Connect the cables inside the camera adapter.
- ② Loosen the dome cover torx screws (3ea) and remove the dome cover from the camera base.
- ③ Mount the camera base to the #1 holes in the camera adapter using the M4x12 screws (4ea) supplied with the camera with o-rings attached.
- ④ Attach the dome cover to the camera base using the dome cover torx screws (3ea) with o-rings attached.

